

RichardSolo Noise Canceling Headphones

INSTRUCTION MANUAL

Model FJ001

Using your RichardSolo Noise Canceling Headphones

1. Insert the 3.5mm audio plug into a headphone jack.
(Use included airplane jack adapter when applicable.)
2. For optimal noise cancellation, slide the **ON/OFF** switch located on the back of the right headphone to the **ON** position.
3. Rotate folded section of headphones to open position. Place on your head and adjust to a comfortable fit.
4. Adjust the volume of the audio source.



Technical Specifications

Noise canceling:	15dB at 300Hz
Impedance:	32 ohms
Maximum power output:	60mW (P.M.P.O.)
Sensitivity:	116dB (off) 122dB (on)
Plug type:	3.5mm gold-plated stereo
Cord length:	1.6m

Battery Installation

1. Slide the battery cover, located on the right side of the headband, up and out.
2. Insert one AAA battery (included), observing +/- polarities diagram located inside the battery compartment.
3. Close the battery cover.

Warning

Do not use headphones at excessive volume levels. Prolonged use at high volume may cause hearing impairment.

Limited Warranty

The RichardSolo Noise Canceling Headphones have a 90-day warranty against defects in material or workmanship.

Questions? Please email us at: support@richardsolo.com

RichardSolo, 336 Bon Air Center #435, Greenbrae, CA 94904 USA

www.richardsolo.com